


DQ301-01
INLINE TABLE,
WOOD



DQ301-02
INLINE TABLE,
METAL



#12 x 7/8"
HEX HD
THREAD FORMING
SCREWS
QTY 8

Tools required for assembly

- Safety glasses
- 6ft level
- tape measure
- 5/16" wrench or socket

INSTALLATION: Refer to specifier's plan drawings for location and design of inline tables. Inline tables are designed to be installed in front of Backdrop wall panels. Tables cannot be installed on L-shaped walls.

1. Refer to installation guide for Backdrop posts, connectors and wall panels.
2. Locate wall sections on plan for installation of inline table. Determine mounting height as specified in customer provided plan or follow recommendations noted in Fig. 1 or Fig. 2.
3. Place inline table in position. Front of bracket should be flush with front of post. Install thread forming screws on one bracket.
4. Level the tabletop. Install remaining thread forming screws on opposite side bracket.

ASSEMBLE WITH CARE! Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.




Fig. 1 – INSTALL INLINE TABLE AT DINING HT




Fig. 2 – INSTALL INLINE TABLE AT STANDING HT