



Included components



Tools Required

- Safety glasses
- hex key: 5/32"

Surface mount option:



Included components

Tools Required

- hammer drill with 1/2" dia bit
- epoxy anchoring system for concrete
- flat head screwdriver
- hex key, 5/32"
- 1/2" wrench

WARNING!: LED cartridge and driver are not rated for connection or disconnection while energized. Doing so may damage LEDs and will void the warranty. Disconnect incoming power before making or breaking any electrical connections.

INSTALLATION PROCEDURE FOR ASSEMBLING THE FLOOR LAMP:

1. Make wiring connection from harness in lighted arm to the connector at the top of the round pole, see Fig. 1.
2. Carefully slide lighted arm over the bracket at the top of the round pole. Align two holes in back of arm. Secure with (2) 1/4-20 x 1/2" flat head socket cap screws, see Fig. 2.
3. Place unit in position and plug in cord. Power on and off by using switch on cord.




Fig. 1 – install lighted arm




Fig. 2 – Install screws to secure arm

INSTALLATION PROCEDURE FOR ANCHORING THE FREESTANDING UNIT:

1. Using flat head screwdriver and ½" wrench, remove plug hardware in anchoring hole, see Fig. 3.
2. Remove set screw from plug.
3. Thread 1-1/2" long set screw from hardware pack into plug, see Fig. 4.
4. Set floor lamp in position.
5. Mark anchor hole location and remove the template.
6. Drill hole according to anchor size and depth, see Fig. 5. Clear hole of debris.
7. Test fit anchor into position before installing epoxy. Make any adjustments as necessary to allow concrete anchor to freely install. Concrete anchor should sit centered in hole and not rest against the side of the drilled hole.
8. Add epoxy to anchor hole per epoxy manufacturer's recommendations.
9. Slowly set anchor into position. Wipe away any excess epoxy before it cures.
10. Allow epoxy to fully cure.
11. Move floor lamp into position and install plug with set screw into anchor.




Fig. 3 – Remove plug to anchor freestanding unit




Fig. 4 – thread 1-1/2" set screw into plug




Fig. 5 – Anchor detail