

Instructions

Assembly
Installation
Operation

7/2007

Parc Vue™ Litter Receptacle

HANDLE WITH CARE! Pangard II® Polyester Powder coat is a strong, long-lasting finish. Protect this finish from damage during installation. Place unwrapped powder coated parts on packaging foam or other non-abrasive surface. Do not place or slide powder coated parts on concrete or other hard or abrasive surfaces – this will damage the finish causing rust to occur. Use touch-up paint to repair any finish abrasions.

Recommended Procedure for Surface Mounting:

1. All litter receptacle bases have a center hole that will accommodate anchors 1/2" diameter or less.
2. The installer is responsible for anchoring hardware suitable for site conditions. Corrosion resistant anchors are recommended. The receptacle should be surface mounted with nylon glides in place.
3. Place the unit in the desired position.
4. Remove the top and lift out the liner.
5. Mark anchor location through the hole in the base.
6. Move the unit to allow access for drilling holes.
7. Complete the installation according to the anchor manufacturer's instructions.

