www.landscapeforms.com

Date: March 9, 2015 Ph: 800.521.2546







Top Opening Unit

Tools Required

- Safety glasses
- Litter receptacle ships fully assembled with freestanding glides.
- Surface mount option: anchoring hardware not included. Two anchors, 3/8" diameter or less, are required per unit. The base casting adds 1-1/8" to the anchor length. The installer is responsible for anchoring hardware suitable for site conditions. Corrosion resistant anchors are recommended.


PROCEDURE FOR INSTALLATION:

FOR SURFACE MOUNTED LITTER RECEPTACLE:


Note: Unit can be surface mounted with freestanding glides installed.

- 1. Place the unit in the desired position. Lift the lid to check clearance.
- 2. Remove the liner and mark anchor locations through the holes in the base.
- 3. Move the unit to allow access for drilling holes.
- 4. Drill holes at marked locations according to anchor manufacturer's specification.
- Complete the anchor installation according to the anchor manufacturer's instructions.

ASSEMBLE WITH CARE! Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface — this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.



Base section view



Base bottom view

