


4-section planter

Included components: 2 'A' sections, 2 'B' sections



<b>Mirador</b>	1 section
Weight (lbs)	2187
Area of Base (in <sup>2</sup> )	950
Pressure (lb/in <sup>2</sup> )	2.30

Tools required:

- Crane or forklift.
- Straps
- Silicone sealer for joints

NOTE: Items will deliver on pallets in closed freight containers. Appropriate equipment will be required to offload from a closed container.

Flatbed delivery is possible upon request and for an additional charge.

Strapping is indicated as a method of placing the item on the project site.

**INSTALLATION:**

1. Determine placement of planter.
2. Set one section in position with proper equipment such as a forklift or crane. See Fig. 1. See included components section for proper placement to create finished planter. Repeat for remaining sections.
3. Seal joints with silicone sealer to prevent runoff of planting materials.




Fig. 1 – Crane install – strap locations