




OPERATING INSTRUCTIONS

OCEAN MASTER MAX AND PLANTATION MAX WITH AUTO LOCK LIFT

- ① Remove all packaging from umbrella, including inside the umbrella.
- ② Pull pin to unlock cam lock handle. Make sure cam lock handle is open per drawing shown.
- ③ Insert cover on to mast.
Place Umbrella in SECURITY STEM.
- ④ Push cam lock handle (per drawing shown) until engaged in the proper gear slot with the cam lock handle in the downward position.

** To rotate umbrella: Pull pin to unlock cam lock handle, pull handle up and turn umbrella to desired location. Lock cam lock handle down.*



global headquarters

2900 NW 35th Street
Miami, FL 33142 USA

t 305.634.5116
f 305.634.5119

info@tuuci.com
www.tuuci.com


Version date: 04/01/2013 - REV: C - Page 1 of 2

TUUCI
made in miami

OPERATING INSTRUCTIONS

OCEAN MASTER MAX AND PLANTATION MAX AUTO LOCK LIFT UMBRELLA

- ⑤ Gently separate EACH RIB INDIVIDUALLY from center post, approx. 10-12"/25-30cm. If rib does not move easily, DO NOT force. Inspect product for additional packaging.
- ⑥ Gently pull cord moving main hub up center pole into open position.
- ⑦ Secure marine rope in cam locking cleat on main hub, and hang excess rope coil on rope hook.
- ⑧ To close, remove marine rope off cam locking cleat on main hub. Release the rope slowly because umbrella closes automatically.
- ⑨ Close umbrella during wind conditions that exceed manufacturer's specifications.



global headquarters

2900 NW 35th Street
Miami, FL 33142 USA

t 305.634.5116
f 305.634.5119

info@tuuci.com
www.tuuci.com

Version date: 04/01/2013 - REV: C - Page 2 of 2

TUUCI
made in miami