Installation Instructions

FLUSH MOUNT CENTER POST PARASOLS
INSTALLATION IN CONCRETE

1. Draw a pattern on concrete with dimensions shown on the drawing.
2. Drill holes on concrete as per the drawing is shown.

1





FLUSH MOUNT CENTER POST PARASOLS



FLUSH MOUNT
ID1 ¾" PATTERN

2

DRILLING HOLES MACHINE



global headquarters

2900 NW 35th Street
Miami, FL 33142 USA

t 305.634.5116
f 305.634.5119

info@tuuci.com
www.tuuci.com

Installation Instructions

FLUSH MOUNT CENTER POST PARASOLS
INSTALLATION IN CONCRETE

3. Drill 3 holes in pattern with a 0.5" drill, 1.5" deep.
4. Clean the holes by using dry compressed air and a clean wire brush.Dust and debris left in hole will significantly reduce the holding capacity of the anchor.
5. Insert "Drop in" anchors with a 0.25" spike.
6. Hammer open flange on "Drop in" anchors.
7. Install flush mount.Then securely tighten screws (3/8"-16) with screwdriver. Retighten periodically.

3



0.5" drill, 1.5" deep.

4



5



6



0.25" Spike

7



global headquarters

2900 NW 35th Street
Miami, FL 33142 USA

t 305.634.5116
f 305.634.5119

info@tuuci.com
www.tuuci.com

Installation Instructions

FLUSH MOUNT CENTER POST PARASOLS
INSTALLATION IN CONCRETE

8. Insert Bayonet Sleeve as per the drawing shown.
9. Insert Hitch Pin through from Flush Mount to Bayonet Sleeve.
10. Insert center post parasol to Bayonet Sleeve and touch on Hitch Pin.
11. Adjust umbrella right direction then drill hole 9/32" on two sides of Bayonet Sleeve.
12. Insert Hitch Pin through from Bayonet Sleeve to Center Post Parasol.











global headquarters

2900 NW 35th Street
Miami, FL 33142 USA

t 305.634.5116
f 305.634.5119

info@tuuci.com
www.tuuci.com