


Standing ht SUPPORT 'A'




Standing ht SUPPORT 'B'




Footrest




30" dia tabletop,
Marneaux or Catena




27" square wood
Tabletop




30" dia wood
Tabletop



30" square Marneaux
Tabletop



Backless
Grid seat




Backless
perf seat



Backed
grid seat



Backed
perf seat




Hoop
seat

Included components:

- Support 'A' with surface mount tabs
- Support 'B' with surface mount tabs
- Footrest
- Seats (qty and style depends on order)
- 1 tabletop per unit, with attaching hardware
- (1) 1/4-20 x 2-1/4" Phillips pan head machine screw and lock nut



2X - 1/4 washer



2X - 1/4-20 x 7/8"
Hex head cap screws



4X - 3/8-16 x 1-
1/2" indented hex
head machine
screw



4X - 3/8 washer

ASSEMBLE WITH CARE! Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.

WARNING! TABLES MUST BE FASTENED SECURELY TO HARD SURFACING TO PREVENT TIPPING.

Tools required:

- protective padding
- 3/16 hex key
- Anchoring hardware not included for surface mount units. Powers Fasteners Power-Bolt® stainless steel 3/8" x 2-1/4" hex head sleeve anchors are recommended. (4 required)
- Hammer drill with 3/8" diameter carbide tipped drill bit
- Hammer
- Wrench
- 9/16" wrench (for seats)
- 5/32" hex key
- 7/16" wrench (for umbrella hardware)

PROCEDURE FOR ASSEMBLING SUPPORTS: See Fig 1 and Fig 2

Note: DO NOT DRAG unit across concrete or other rough surfaces. This could damage the powdercoat on the bottom of the surface mount tabs.

1. Verify that surface mount tabs are securely fastened to support legs. Tighten if necessary.
2. Slide support 'A' over support 'B'. Align notch in support 'A' over bar in support 'B'. See Fig. 1.
3. Slide footrest over assembled support legs, aligning the holes in the footrest with the holes in the support bar.
4. Secure footrest to support legs with (2) hex head cap screws and washers. See Fig. 2.

TABLETOP ASSEMBLY: See Fig 3.

Note: DO NOT DRAG unit across concrete or other rough surfaces. This could damage the powdercoat.

1. Place table top upside down on non-marring level surface.
2. Place assembled support on tabletop. Align holes in brackets on support with holes in tabletop.
3. Loosely fasten support to table top with screws provided.
 - Catena/Steelhead tables include (12) 1/4-20 x 3/4" Phillips truss head tapping screws
 - Marneaux® includes (4) 1/4-20 x 3/4" Phillips pan head machine screws and washers. One screw required at the outer hole in each plate.
 - Square wood tabletop includes (12) 1/4-20 x 1" Phillips pan head machine screws.

The use of power drivers is not recommended. Threads or threaded inserts may be damaged or broken due to over-torqueing.

4. Install hardware. Tighten all table top fasteners until snug, then tighten additional 1/4 turn.
5. Turn table right side up using at least two people.

PROCEDURE FOR ASSEMBLING SEATS: See Fig 4.

Note: These instructions apply to all seat styles for Carousel units. Seats were NOT designed to swivel. Allowing the seat to swivel will damage the finish and the product.

1. Slide seat stem into tube on support. Backless seats should be installed with the flat part of the stem facing in toward the center of the table.
2. Align threaded hole in seat stem with hole in support tube. This may require lifting the seat slightly.
3. Insert washer and hex head machine screw through the support hole and tighten. Screws are coated with a dry thread locking compound that cures in 24 hours. Wiggle seats and tighten as necessary until seat is securely fastened,

SURFACE MOUNT INSTALLATION:

1. Place unit in desired position and mark anchor locations through holes provided in surface mount tabs.
2. Move unit and drill holes.
3. Clear the holes of dust and debris using compressed air.
4. Place unit in desired position and install all of the anchors. After all anchors are installed, tighten as recommended by anchor manufacturer.
5. Periodically check fasteners and tighten if required.

UMBRELLA ASSEMBLY:

1. To install umbrella, slide umbrella pole through hole in table and into tube on support "B".
2. Align holes in base tube and umbrella pole. Insert long 1/4-20 machine screw and secure with lock nut.

CAUTION: Do not let go of the umbrella until the pole has been secured.

WARNING! All standing height units must be anchored.




Fig. 1 – Assemble support legs




Fig. 2 – Attach footrest




Fig. 3 – Install tabletop




Fig. 4 – Install seat