


## Bench options

Included components: bench ships fully assembled

## Surface Mount



3/8-16 x 1-3/8" long  
Hex bolt  
2X – backless bench  
4X – backed bench



3/8-16 washer  
2X – backless bench  
4X – backed bench



Concrete grip anchor,  
3/8-16 thread  
2X – backless bench  
4X – backed bench

## Tools Required

- Safety glasses
- Hammer drill with 9/16" dia masonry drill bit
- Hammer
- 9/16" wrench
- epoxy anchoring system
- compressed air for clearing anchor holes of debris

**ASSEMBLE WITH CARE!** Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.

## PROCEDURE FOR INSTALLATION:

1. Prepare wall as required.

**Note:** Landscape Forms is not responsible for wall installation.

**Note:** DO NOT DRAG bench across concrete or other rough surfaces. This could damage the powdercoat finish.

2. Place unit in desired position and mark anchor locations through holes provided in base plate. See Figures 2 and 3 for minimum concrete base requirements.
3. Move unit and drill holes using 9/16" dia. drill bit, see Fig. 1.
4. Clear the holes of dust and debris using compressed air.
5. Fill holes with epoxy as directed by epoxy manufacturer.
6. Install concrete grip anchors so top of anchor is flush or just below grade.
7. Move unit in position.
8. Install hex bolts, washers and nuts. Do not tighten fully until epoxy has cured.
9. Periodically check fasteners and tighten if required.




Fig. 1 – anchor hole size




Fig. 2 – wall recommendations backless bench




Fig. 3 – wall recommendations backed bench