



## Included components



1x – wooden drill template



Anchor kit

Included: hardware is galvanized

- (3) anchor bolts, 3/4" -10 x 17" x 3" hook ,
- (6) heavy hex nuts, 3/4" x 10
- (6) flat washers, .81 ID" x 1.5" OD x 0.13" thick

## Tools Required

- Safety glasses
- Wrenches, 1-1/8"
- Level

## LIGHTING LAYOUT RECOMMENDATIONS:

Refer to the product data sheet available at [www.landscapeforms.com](http://www.landscapeforms.com) for recommendations for light pole spacing.

**Landscape Forms is not responsible for site preparation and footings. Refer to pole drawings for pole calculations required for footing design.**

**ASSEMBLE WITH CARE!** Pangard II® Polyester Powdercoat is a strong, long-lasting finish. To protect this finish during assembly, place unwrapped powdercoated parts on packaging foam or other non-marring surface. Do not place or slide powdercoated parts on concrete or other hard or textured surface – this will damage the finish causing rust to occur. Use touch-up paint on any gouges in the finish caused by assembly tools.

## INSTALLATION PROCEDURE FOR ANCHOR BOLTS:

Note: Conduit opening on base plate accepts up to (3) 3/4" trade size PVC conduits.

1. Prepare footing as required by local codes.
2. Template mark "F" indicates where the front arm of the unit should align. The front arm is 180deg opposite from the handhole.
3. Assemble template and anchors as shown in Fig. 1. Set into new concrete. Level template in all directions.
4. After footing has properly cured, remove wooden template. Do not remove lower hex nuts or washers.




FIG. 1 – ANCHOR INSTALL DETAIL




FIG. 2 – TEMPLATE DETAIL